



- CAFE TABLES SHIP IN THREE (3) SEPARATE CARTONS. 1-TOP, 1-BASE-BOTTOM DISC, 1-BASE COLUMN
- 

1. Place the work surface upside down on a cardboard or carpeted surface to prevent finish from scratching.
2. Place the column on the top and align the six (6) holes in the mounting plate with the predrilled holes in the top.
3. Using a screwdriver, secure the column to the top with the six (6) #12-7/8" screws included in the hardware pack.




4. With the column fully secured to the top, place the base plate on column and align the four (4) holes in the center of the base plate to the four (4) holes in the inner ring in the column.



5. Screw in the five (5) nylon glides into the bottom of the base plate.

1. Before installing the base to the top, follow the installation instructions included with the grommet mount power units (PDC-3G20, PDC-MG22, PDC-MG40) to secure the power unit to top.
2. Place the top upside down on cardboard or carpeted spacers to prevent the table from resting on the power unit while installing the base. Feed the power cord through the column and hole in the base, and install the base as above, starting with Step 2.



3. For racetrack shaped tops with a single grommet mount power unit, feed the cord through the slot in the column and route the cord through the hole in the base.

