



- Tops and Legs ship in separate cartons

1. Place the work surface upside down on a cardboard or carpeted surface to prevent finish from scratching.
2. Place the triangular Leg Plate on the top and slide beneath the Quick-Set Bracket in the direction shown in Figure 1.

**NOTE:** A plastic or rubber mallet may be used to lightly tap the leg beneath the Quick-Set Bracket. In the event that the triangular Leg Plate does not slide underneath the Quick-Set Bracket with light tapping of the mallet, the screws identified "A" in Figure 1 below may be slightly loosened and then retightened to enable the triangular Leg plate to slide beneath the Quick-Set Bracket.




3. With the Leg Plate now fully seated underneath the Quick-Set Bracket, install (3) Philips head, #10 x 3/4" screws provided in the hardware pack in the 3 holes identified "B" as indicated below in Figure 2.



**Figure 2**

4. Adjust leg to desired height by loosening the two 5/16" Philip Pan Head screws, sliding the leg insert in or out of the receiver until the desired height setting is reached. Retighten the two 5/16" Philip Pan Head screws ensuring that the corresponding holes in the Leg Insert aligns with the Philip Pan Head screws. See Figure 3 below.



**Figure 3**