







- Use Application Matrix to confirm compatibility with specified student desk
- Use Application Matrix to determine if top is factory pre-drilled for accessories
- Use Screw type Matrix to select proper screw by top material type

				
	POLY	WIRE	FULL METAL	HOOK
APPLICATION GUIDE	Universal	Small		
Model Number	TA-BBP16	TA-BBW15	TA-BBFM17	TA-BPH
Width	16"w	15"w	17.5" w	2.25"w
Depth	13.25"d	13.25"d	14.0" d	1.22"d
Height	3.5"h	5.25"h	5.0" h	2.35"h
18" x 24" (7SD4A0, 7SD4H0)	YES	YES	NO	YES
20" x 26" (7SD4A6, 7SD4H6)	YES	YES	YES	YES
Tri- Top (7SD3A, 7SD3H)	YES	YES	YES	YES
Trapezoid (7SD4AT)	YES	YES	YES	YES
Shape Student Desks (excludes Trek)	YES	YES	YES	YES
Shape Student Desk 20" x 36" ONLY	YES	YES	YES	YES
4100 Series Cantilever Desk	YES	YES	YES	YES

IMPORTANT | Use proper screw type

All book boxes and backpack hooks include a hardware pack with BOTH wood screws and solid plastic screws. Check top material to make sure the correct screws are used.

SCREW TYPE		PLASTIC BOOK BOX	WIRE FRAME BOOK BOXES	FULL METAL	BACK PACK HOOK
Material	Screw Type	TA-BBP16	TA-BBW15	TA-BBFM17	TA-BPH1
Laminate		#12 x 3/4" Pan head Sheet Metal Screw Artcobell P/N 800200	#10-10 x 5/8" Pan head Wood Screw Artcobell P/N 804100		#10-10 x 17/32" Pan head Wood Screw Artcobell P/N 800500
Solid Plastic			#10 x 1/2" Pan head Type 25 Artcobell P/N 800301		

1. Place the work surface upside down on a cardboard or carpeted surface to prevent finish from scratching.


2. IMPORTANT | Pre-Drill Solid Plastic tops

- For SOLID PLASTIC tops, mark holes and use a drill with #24 size drill bit and drill ½” deep pilot holes. Use screwdriver to secure book box with included SOLID PLASTIC SCREWS.
DO NOT INSTALL WITHOUT PRE-DRILL HOLES. DO NOT OVER TORQUE SCREWS.
- For LAMINATE tops, pre-drill not required. Use screwdriver to secure book box with included WOOD SCREWS.
DO NOT OVER TIGHTEN SCREWS.


FOR INSTALLATION ON TOPS THAT ARE NOT PRE-DRILLED

Book Boxes

- Place the work surface upside down on a cardboard or carpeted surface to prevent finish from scratching.
- Position front edge of book box ½” back from front edge of top. Center book box side to side between legs on underside of work surface.
- For Solid Plastic tops, using the book box mark holes and then pre-drill per Page 1 STEP #2. Once pre-drill holes are complete, use screwdriver to secure book box with included screws for Solid Plastic tops
- For Laminate tops, use screwdriver to secure book box with included screws for laminate tops.




7SD4 Desks




7SD3 Tri-To

Back Pack Hooks




7SD4 Student Desks

Position backpack hook so mounting holes align with holes in the leg bracket. Follow book box steps #3 & #4



4100 Series Cantilever Desks

Inset backpack hook ¼” from the side edge of the top, and 2” from the back edge. Follow book box steps #3 & #4



7SD3 Tri-Top Desks

Inset backpack hook ¼” from the edge of the top and 6” from the back perpendicular edge. Follow book box steps #3 & #4